

# INSTALLATION INSTRUCTIONS

## 掛勾安裝說明

### Robe Hook

1. Select a proper position for product and mark the center of drilling.  
請先選取預定安裝的位置,並在安裝面上畫上預定鑽孔記號。
2. Use a 6mm drill-bit to drill a hole at marked position to the depth of 4cm.  
Insert the Plastic Anchor and make it be flush with surface of wall.  
當安裝在水泥牆,使用6mm鑽頭,鑽孔深度4公分, 嵌入塑膠塞並使之齊平於牆面
3. Screw the Hook Body into the Plastic Anchor till hand tight.  
將掛勾本體鎖入塑膠塞中,依個人喜好調整掛勾方向,鎖緊後即可完成安裝。

